GARMIN®



DĒZL™ OTR700 / LGV700

Owner's Manual

© 2020 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These trademarks may not be used without the express permission of Garmin.

dēzl™, Garmin Drive™, Garmin eLog™, Garmin Express™ and myTrends™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Android™ is a trademark of Google Inc. Apple®, iPhone®, and Mac® are trademarks of Apple Inc, registered in the U.S. and other countries. The BLUETOOTH® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license.Foursquare® is a trademark of Foursquare Labs, Inc. in the U.S. and in other countries. microSD® and the microSDHC logo are trademarks of SD-3C, LLC. TripAdvisor® is a registered trademark of TripAdvisor LLC. TruckDown® is the trademark of TruckDown Info International, Inc.Wi-Fi® is a registered mark of Wi-Fi Alliance Corporation.Windows® is a registered trademark of Microsoft Corporation in the United States and other countries.

Table of Contents

Getting Started 1
dēzl OTR700 / LGV700 Device Overview 1
Mounting and Powering the dēzl Device in Your Vehicle 1
Turning the Device On or Off 1
Acquiring GPS Signals 1
Status Bar Icons 1
Using the On-Screen Buttons 2
Adjusting the Volume 2
Using the Audio Mixer 2
Adjusting the Screen Brightness 2

Vehicle Profiles 2
Adding a Vehicle Profile 2
Switching the Vehicle Profile 2
Changing Your Trailer Information 2
Editing a Vehicle Profile 2

Driver Awareness Features and Alerts 2
Enabling or Disabling Driver Alerts 3
Red Light and Speed Cameras 3

Finding and Saving Locations 3
Finding a Location Using the Search Bar 3
Finding an Address 3
Location Search Results 4
Location Search Results on the Map 4
Changing the Search Area 4
Points of Interest 4
Finding Trucking Points of Interest 4
Finding TruckDown Points of Interest 4
Finding a Location by Category 4
Foursquare 5
TripAdvisor® 5
Navigating to Points of Interest Within a Venue 5
Search Tools 5
Finding an Intersection 5
Finding a Location Using Coordinates 5
Parking 5
Finding Truck Parking 5
Finding Truck Parking in Europe 5
Finding Parking Near Your Current Location 5
Finding Parking Near a Specified Location 5
Understanding Parking Colors and Symbols 6
Viewing Recently Found Locations 6
Clearing the List of Recently Found Locations 6
Viewing Current Location Information 6
Finding Emergency Services and Fuel 6
Getting Directions to Your Current Location 6
Saving Locations 6
Saving a Location 6
Saving Your Current Location 6
Editing a Saved Location 6
Assigning Categories to a Saved Location 6
Deleting a Saved Location 6

Following a Route 6
Routes 6
Starting a Route 7
Starting a Route by Using the Map 7
Going Home 7
Your Route on the Map 7
Active Lane Guidance 7
Viewing Turns and Directions 7
Viewing the Entire Route on the Map 7
Arriving at Your Destination 8
Completing a Truck Route 8
Parking Near Your Destination 8
Changing Your Active Route 8
Adding a Location to Your Route 8
Shaping Your Route 8
Taking a Detour 8
Changing the Route Calculation Mode 8
Stopping the Route 9
Using Suggested Routes 9
Avoiding Delays, Tolls, and Areas 9
Avoiding Traffic Delays on Your Route 9
Avoiding Toll Roads 9
Avoiding Toll Stickers 9
Avoiding Road Features 9
Avoiding Environmental Zones 9
Custom Avoidances 9

Using the Map 9
Map Tools 10
Viewing a Map Tool 10
Up Ahead 10
Viewing Upcoming Locations 10
Customizing the Up Ahead Categories 10
Cities Ahead 10
Viewing Upcoming Cities and Exit Services 10
Trip Information 10
Viewing Trip Data from the Map 10
Viewing the Trip Information Page 11
Resetting Trip Information 11
Viewing Upcoming Traffic 11
Viewing Traffic on the Map 11
Searching for Traffic Incidents 11
Customizing the Map 11
Customizing the Map Layers 11
Changing the Map Data Field 11
Changing the Map Perspective 11

Live Services, Traffic, and Smartphone Features 11
Pairing with Your Smartphone 11
Disabling Bluetooth Features (Android™) 11
Disabling Bluetooth Features (iPhone®) 12
Bluetooth Feature Status Icons 12
Smart Notifications 12
Receiving Notifications 12
Viewing the List of Notifications 12
Going to an Address or Location Using the Garmin Drive App 12
Hands-Free Calling 13
Placing a Call 13
Receiving a Call 13
Using the Call History 13
Using In-Call Options 13
Saving a Home Phone Number 13
Deleting a Paired Phone 13

Traffic 13
Receiving Traffic Data Using Your Smartphone 13
Receiving Traffic Data Using a Traffic Receiver 14
Traffic Receiver Subscriptions 14
Enabling Traffic 14
Viewing Traffic on the Map 14
Searching for Traffic Incidents 14

Vehicle and Driver Tools 14
Break Planning 14
Taking a Suggested Break 14
Starting the Break Timer 14
Pausing and Resetting the Break Timer 14
Adjusting Drive Hours 14
Adjusting the Daily Driving Limit 14
Garmin eLog 14

Setting Up Garmin eLog Features On Your dēzl Device 15
Viewing Garmin eLog Information on Your dēzl Device 15
Viewing Garmin eLog Diagnostic and Malfunction Events .. 15
IFTA 15
Entering Fuel Data 15
Editing Fuel Data 15
Viewing and Exporting a Jurisdiction Summary 15
Editing and Exporting Trip Reports 15
Viewing Exported Jurisdiction Summaries and Trip Reports 15
Logging Service History 16
Adding Service Categories 16
Deleting Service Categories 16
Renaming Service Categories 16
Deleting Service Records 16
Editing a Service Record 16
Voice Command 16
Tips for Speaking to the Device 16
Launching Garmin Voice-Activated Navigation 16
Checking Your Arrival Time 16
Placing a Phone Call Using Your Voice 16
Changing Device Settings Using Your Voice 16
Using the Apps 16
Viewing the Owner's Manual on Your Device 16
Viewing the Weather Forecast 16
Viewing Weather Near a Different City 17
Viewing the Weather Radar 17
Viewing Weather Alerts 17
Checking Road Conditions 17
Trip Planner 17
Planning a Trip 17
Editing and Reordering Locations in a Trip 17
Discovering Attractions Along Your Trip 17
Changing Routing Options for a Trip 17
Navigating to a Saved Trip 17
Editing and Saving Your Active Route 17
photoLive Traffic Cameras 18
Viewing and Saving photoLive Traffic Cameras 18
Viewing photoLive Traffic Cameras on the Map 18
Saving a Traffic Camera 18
Viewing Previous Routes and Destinations 18
Settings 18
Map and Vehicle Settings 18
Enabling Maps 18
Navigation Settings 18
Calculation Mode Settings 18
Setting a Simulated Location 18
Wireless Network Settings 18
Driver Assistance Settings 19
Proximity Alerts Settings 19
Backup Camera Settings 19
Display Settings 19
Traffic Settings 19
Units and Time Settings 19
Setting the Time 19
Language and Keyboard Settings 19
Device and Privacy Settings 19
Resetting Data and Settings 19
Device Information 20
Viewing E-label Regulatory and Compliance Information 20
Specifications 20
Charging the Device 20
Device Maintenance 20
Garmin Support Center 20
Map and Software Updates 20
Connecting to a Wi-Fi Network 20
Updating Maps and Software Using a Wi-Fi Network 20
Updating Maps and Software with Garmin Express 20
Device Care 21
Cleaning the Outer Casing 21
Cleaning the Touchscreen 21
Avoiding Theft 21
Restarting the Device 21
Removing the Device, Mount, and Suction Cup 21
Removing the Device from the Mount 21
Removing the Mount from the Suction Cup 21
Removing the Suction Cup from the Windshield 21
Changing the Fuse in the Vehicle Power Cable 21
Troubleshooting 22
The suction cup will not stay on my windshield 22
My device is not acquiring satellite signals 22
The device does not charge in my vehicle 22
My battery does not stay charged for very long 22
My device does not connect to my phone 22
Appendix 22
Installing a Memory Card for Maps and Data 22
Data Management 22
About Memory Cards 22
Connecting the Device to Your Computer 22
Transferring Data From Your Computer 22
Disconnecting the USB Cable 22
Viewing GPS Signal Status 23
Purchasing Additional Maps 23
Purchasing Accessories 23
Index 24

Getting Started

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

- Update the maps and software on your device (*Map and Software Updates*, page 20).
- Mount the device in your vehicle and connect it to power (*Mounting and Powering the dēzl Device in Your Vehicle*, page 1).
- Acquire GPS signals (*Acquiring GPS Signals*, page 1).
- Adjust the volume (*Adjusting the Volume*, page 2) and display brightness (*Adjusting the Screen Brightness*, page 2).
- Set up a vehicle profile for your truck (*Adding a Vehicle Profile*, page 2).
- Navigate to your destination (*Starting a Route*, page 7).

dēzl OTR700 / LGV700 Device Overview

①	Power key
②	USB power and data port
③	Map and data memory card slot
④	Microphone for Voice Command or hands-free calling

Mounting and Powering the dēzl Device in Your Vehicle

⚠ WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

Before you use your device on battery power, you should charge it.

1. Plug the vehicle power cable ① into the USB port on the device.



2. Press the mount ② onto the suction cup ③ until it snaps into place.
3. Press the suction cup to the windshield, and flip the lever ④ back toward the windshield.
4. Fit the tab on the top of the mount into the slot on the back of the device.
5. Press the bottom of the mount into the device until it clicks.
6. Plug the other end of the vehicle power cable into a power outlet in your vehicle.

Turning the Device On or Off

- To turn the device on, press the power key ①, or connect the device to power.

- To put the device in power saving mode, press the power key while the device is on.

  While in power saving mode, the screen is off and the device uses very little power, but it can wake instantly for use.

  TIP: You can charge your device faster by putting it in power saving mode while charging the battery.
- To turn off the device completely, hold the power key until a prompt appears on the screen, and select **Off**.

  The prompt appears after five seconds. If you release the power key before the prompt appears, the device enters power saving mode.

Acquiring GPS Signals

When you turn on your navigation device, the GPS receiver must collect satellite data and establish the current location. The time required to acquire satellite signals varies based on several factors, including how far you are from the location where you last used your navigation device, whether you have a clear view of the sky, and how long it has been since you last used your navigation device. The first time you turn on your navigation device, it may take several minutes to acquire satellite signals.

1. Turn on the device.
2. Wait while the device locates satellites.
3. If necessary, go to an open area, away from tall buildings and trees.

in the status bar indicates the satellite signal strength. When at least half the bars are filled, the device is ready for navigation.

Status Bar Icons

The status bar is located at the top of the main menu. The status bar icons display information about features on the device. You can select some icons to change settings or view additional information.

	GPS signal status. Hold to view GPS accuracy and acquired satellite information (*Viewing GPS Signal Status*, page 23).
	Bluetooth® technology status. Select to view the Bluetooth settings (*Wireless Network Settings*, page 18).
	Wi-fi signal strength. Select to change the wi-fi settings (*Wireless Network Settings*, page 18).
	Connected to hands-free calling. Select to place a phone call (*Hands-Free Calling*, page 13).
	Active vehicle profile. Select to view the vehicle profile settings (*Editing a Vehicle Profile*, page 2).
	Garmin eLog™ status. Select to view the current ELD information. When the icon is blue, the device is connected to the Garmin eLog app.

9:10	Current time. Select to set the time (*Setting the Time*, page 19).
	Battery charge level.
	Garmin Drive™ app connection status(*Pairing with Your Smartphone*, page 11).
53°F	Temperature. Select to view the weather forecast (*Viewing the Weather Forecast*, page 16).

Using the On-Screen Buttons

On-screen buttons allow you to navigate the pages, menus, and menu options on your device.

- Select to return to the previous menu screen.
- Hold to quickly return to the main menu.
- Select or to scroll through lists or menus.
- Hold or to scroll faster.
- Select to see a context-based menu of options for the current screen.

Adjusting the Volume

1. Select **Volume**.
2. Select an option:
   - Use the slider bar to adjust the volume.
   - Select to mute the device.
   - Select a check box to enable or disable additional sound options.

Using the Audio Mixer

You can use the audio mixer to set the volume levels for different audio types, such as navigation prompts or phone calls. The level for each audio type is a percentage of the master volume.

1. Select **Volume**.
2. Select **Mixer**.
3. Use the sliders to adjust the volume for each audio type.

Adjusting the Screen Brightness

1. Select **Settings** > **Display** > **Brightness**.
2. Use the slider bar to adjust the brightness.

Vehicle Profiles

⚠ WARNING

Entering your vehicle profile characteristics does not guarantee that your vehicle's characteristics will be accounted for in all route suggestions or that you will receive the warning icons in all cases. Limitations may exist in the map data such that your device cannot account for these restrictions or road conditions in all cases. Always defer to all posted road signs and road conditions when making driving decisions.

Routing and navigation are calculated differently based on your vehicle profile. The activated vehicle profile is indicated by an icon in the status bar. The navigation and map settings on your device can be customized separately for each vehicle type.

When you activate a truck vehicle profile, the device avoids including restricted or impassable areas in routes based on the dimensions, weight, and other characteristics you entered for your vehicle.

Adding a Vehicle Profile

You can add a vehicle profile that includes the weight, dimensions, and other characteristics for your vehicle.

1. Select **Settings** > **Vehicle Profile** > .
2. Select an option:
   - To add a straight truck with a permanently attached cargo area, select **Straight Truck**.
   - To add a tractor or a tractor-trailer combination, select **Tractor**.
   - To add a bus, select **Bus**.
3. Follow the on-screen instructions to enter the vehicle characteristics.

After you add a vehicle profile, you can edit the profile to enter additional detailed information, such as the vehicle identification number or trailer number (*Editing a Vehicle Profile*, page 2).

Switching the Vehicle Profile

Each time you turn on your device, it prompts you to select a vehicle profile. You can manually switch another vehicle profile at any time.

1. From the status bar, select the vehicle profile icon, such as or .
2. Select a vehicle profile.

   The vehicle profile information appears, including measurements and weight.
3. Select **Select**.

Changing Your Trailer Information

Before you can change your trailer information, you must enter a vehicle profile for a tractor (*Adding a Vehicle Profile*, page 2).

When you change the trailer on your tractor, you can change the trailer information in your vehicle profile without changing the tractor information. You can switch quickly between frequently used trailers.

1. Select **Settings** > **Vehicle Profile**.
2. Select the tractor vehicle profile to use with the trailer.
3. Select .
4. Select an option:
   - To use a recent trailer configuration, select a trailer configuration from the list.
   - To enter a new trailer configuration, select **New Configuration**, and enter the trailer information.

Editing a Vehicle Profile

You can edit a vehicle profile to change vehicle information or to add detailed information to a new vehicle profile, such as the vehicle identification number, trailer number, or odometer reading. You can also rename or delete a vehicle profile.

1. Select **Settings** > **Vehicle Profile**.
2. Select the vehicle profile to edit.
3. Select an option:
   - To edit the vehicle profile information, select , and select a field to edit.
   - To rename a vehicle profile, select > > **Rename Profile**.
   - To delete the vehicle profile, select > > **Delete**.

Driver Awareness Features and Alerts

⚠ CAUTION

The driver alerts and speed limit features are for information only and do not replace your responsibility to abide by all posted speed limit signs and to use safe driving judgment at all times. Garmin® is not responsible for any traffic fines or citations you receive for failing to follow all applicable traffic laws and signs.

Your device provides features that can help encourage safer driving and increase efficiency, even when you are driving in a

familiar area. The device plays an audible tone or message and displays information for each alert. You can enable or disable the audible tone for some types of driver alerts. Not all alerts are available in all areas.

Schools: The device plays a tone and displays the speed limit (if available) for an upcoming school or school zone.

Speed limit exceeded: The device plays a tone and displays a red border on the speed limit icon when you exceed the posted speed limit for the current road.

Speed limit change: The device plays a tone and displays the upcoming speed limit so you can be prepared to adjust your speed.

Wrong way on a one-way street: The device plays a message and displays a full-screen warning if you travel the wrong way on a one-way street. The edges of the screen appear red and an alert remains at the top of the screen until you leave the one-way street or correct your direction of travel.

Railroad crossing: The device plays a tone to indicate an upcoming railroad crossing.

Animal crossing: The device plays a tone to indicate an upcoming animal crossing area.

Curves: The device plays a tone to indicate a curve in the road.

Slower traffic: The device plays a tone to indicate slower traffic when you approach slower traffic at a higher speed. Your device must be receiving traffic information to use this feature (*Traffic*, page 13).

Break planning: The device plays a tone and suggests upcoming rest stops after you have been driving for a long time.

No trucks allowed: The device plays a tone when you approach a road where no trucks are allowed.

Risk of grounding: The device plays a tone and displays a message when you approach a road where your vehicle could become grounded.

Lateral wind: The device plays a tone and displays a message when you approach a road where there is risk of lateral wind.

Narrow road: The device plays a tone and displays a message when you approach a road that may be too narrow for your vehicle.

Steep hill: The device plays a tone and displays a message when you approach a steep hill.

State and country borders: The device plays a tone and displays a message when you approach the border of a state or country.

Enabling or Disabling Driver Alerts

You can enable or disable several types of driver alerts.

1. Select **Settings** > **Driver Assistance** > **Driver Alerts**.
2. Select or clear the check box next to each alert.

Red Light and Speed Cameras

NOTICE

Garmin is not responsible for the accuracy of or the consequences of using a red light or speed camera database.

NOTE: This feature is not available for all regions or product models.

Information about red light and speed camera locations is available in some areas for some product models. The device alerts you when you approach a reported speed or red light camera.

- In some areas, your device can receive live red light and speed camera data while connected to a smartphone running the Garmin Drive app.
- You can use the Garmin Express™ software (garmin.com/express) to update the camera database stored on your device. You should update your device frequently to receive the most up-to-date camera information.

Finding and Saving Locations

The maps loaded in your device contain locations, such as restaurants, hotels, auto services, and detailed street information. The Where To? menu helps you find your destination by providing several methods to browse, search, and save this information.

- Enter search terms to quickly search all location information (*Finding a Location Using the Search Bar*, page 3).
- Browse or search pre-loaded points of interest by category (*Points of Interest*, page 4).
- Search for truck stops and services, including detailed TruckDown® directory information, where available (*Finding Trucking Points of Interest*, page 4).
- Search and check into Foursquare® points of interest (*Searching Foursquare Points of Interest*, page 5).
- Use search tools to find specific locations, such as addresses, intersections, or geographic coordinates (*Search Tools*, page 5).
- Search near a different city or area (*Changing the Search Area*, page 4).
- Save your favorite locations to find them quickly in the future (*Saving Locations*, page 6).
- Return to recently found locations.

Finding a Location Using the Search Bar

You can use the search bar to search for locations by entering a category, brand name, address, or city name.

1. Select **Where To?**.
2. Select **Search** in the search bar.
3. Enter all or part of the search term.

   Suggested search terms appear below the search bar.
4. Select an option:
   - To search for a type of business, enter a category name (for example, "movie theaters").
   - To search for a business name, enter all or part of the name.
   - To search for an address near you, enter the house number and street name.
   - To search for an address in another city, enter the house number, street name, city, and state.
   - To search for a city, enter the city and state.
   - To search for coordinates, enter latitude and longitude coordinates.
5. Select an option:
   - To search using a suggested search term, select the term.
   - To search using the text you entered, select .
6. If necessary, select a location.

Finding an Address

NOTE: The order of the steps may change depending on the map data loaded on your device.

1. Select **Where To?**.
2. If necessary, select to search near a different city or area.
3. Select **Address**.
4. Follow the on-screen instructions to enter address information.

5 Select the address.

Location Search Results

By default, the location search results appear in a list, with the nearest location at the top. You can scroll down to view more results.



①	Select a location to view the option menu.
② ⓘ	Select to view detailed information about the selected location.
③ Ⓟ	Select to find parking areas near the location. **NOTE:** This feature is available only when you are using the car vehicle profile.
④	Select to view alternate routes to the locations.
⑤ Go!	Select to start navigating to the location using the recommended route.
⑥	Select to view the search results on the map.

Location Search Results on the Map

You can view the results of a location search on the map instead of in a list.

From the location search results, select . The nearest location appears at the center of the map, and basic information about the selected location appears at the bottom of the map.

①	Drag the map to view additional search results.
②	Additional search results. Select to view another location.
③	Selected location summary. Select to view detailed information about the selected location.
④ Go!	Select to start navigating to the location using the recommended route.
⑤	Select to view the search results in a list.

Changing the Search Area

By default, the device searches for locations near your current location. You can also search other areas, such as near your destination, near another city, or along your active route.

1 Select **Where To?**.

2 Select next to the current search area ①.



3 Select a search area.

4 If necessary, follow the on-screen instructions to select a specific location.

The selected search area appears next to . When you search for a location using any of the options in the Where To? menu, the device suggests locations near this area first.

Points of Interest

A point of interest is a place that you may find useful or interesting. Points of interest are organized by category and can include popular travel destinations such as gas stations, restaurants, hotels, and entertainment venues.

Finding Trucking Points of Interest

The detailed maps loaded in your device contain trucking points of interest, such as truck stops, rest areas, and weigh stations.

Select **Where To?** > **Categories** > **Trucking**.

Finding TruckDown Points of Interest

The TruckDown directory lists businesses for the trucking industry such as truck repair and tire sales.

The TruckDown directory is not available in all areas.

1 Select **Where To?**.

2 Select an option:

- Select **Truck Locations** to find points of interest compatible with trucks.
- Select **Truck Services** to find service locations for your truck.

3 Select a category.

4 If necessary, select **Search Filters**, select one or more amenities, and select **Save**.

NOTE: This option is available for truck stops only.

5 Select a destination.

Finding a Location by Category

1 Select **Where To?**.

2 Select a category, or select **Categories**.

3 If necessary, select a subcategory.

4 Select a location.

Searching Within a Category

After you have performed a search for a point of interest, certain categories may display a Quick Search list that shows the last four destinations you selected.

1 Select **Where To?** > **Categories**.

2 Select a category.

3 Select an option:

- Select a destination from the quick search list on the right side of the screen.

  The quick search list provides a list of recently found locations in the selected category.

- Select a subcategory, if necessary, and select a destination.

Foursquare

Foursquare is a location-based social network. Your device includes pre-loaded Foursquare points of interest, which are indicated by the Foursquare logo in your location search results.

You can connect to your Foursquare account using the Garmin Drive app on your compatible smartphone. This allows you to view Foursquare location details, check in to a location, and search for points of interest in the online Foursquare database.

Connecting to Your Foursquare Account

Before you can use this feature, your device must be connected to a supported phone running the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

1. On your smartphone, open the Garmin Drive app.
2. Select ⚙ > **Foursquare®**.
3. Enter your Foursquare login information.

Searching Foursquare Points of Interest

You can search for Foursquare points of interest loaded on your device. While your device is connected to your Foursquare account using the Garmin Drive app, the search provides the most up-to-date results from the online Foursquare database and customized results from your Foursquare user account (*Connecting to Your Foursquare Account*, page 5).

Select **Where To?** > **Foursquare®**.

Viewing Foursquare Location Details

Before you can use this feature, your device must be connected to your Foursquare account using the Garmin Drive app (*Connecting to Your Foursquare Account*, page 5).

You can view detailed Foursquare location information, such as user ratings, restaurant pricing information, and hours of operation.

1. From the location search results, select a Foursquare point of interest.
2. Select ⓘ.

Checking in with Foursquare

Before you can use this feature, your device must be connected to your Foursquare account using the Garmin Drive app (*Connecting to Your Foursquare Account*, page 5).

1. Select **Where To?** > **Foursquare®** > **Check In**.
2. Select a point of interest.
3. Select ⓘ > **Check In**.

TripAdvisor®

Your device includes TripAdvisor points of interest and ratings. TripAdvisor ratings appear automatically in the search results list for applicable points of interest. You can also search for nearby TripAdvisor points of interest and sort by distance or popularity.

Finding TripAdvisor Points of Interest

1. Select **Where To?** > **TripAdvisor**.
2. Select a category.

   A list of nearbyTripAdvisor points of interest for the category appears.
3. Select **Sort Results** to sort the search results by distance or popularity (optional).

Navigating to Points of Interest Within a Venue

NOTE: This feature may not be available in all areas or for all product models.

You can create a route to a point of interest (POI) within a larger venue, such as a store in a shopping mall or a specific terminal in an airport.

1. Select **Where To?** > **Search**.
2. Enter the name of the venue, and select 🔍.
3. Select the venue, and select ⓘ.
4. Select **Explore this Venue**, and select a category such as restaurants, car rentals, or terminals to view locations within the venue.
5. Select the POI, and select **Go!**.

The device creates a route to the parking area or venue entrance closest to the POI. When you arrive at the destination, a checkered flag indicates the recommended parking area. A labeled point indicates the location of the POI within the venue.

Search Tools

Search tools allow you to search for specific types of locations by responding to on-screen prompts.

Finding an Intersection

You can search for an intersection or junction between two streets, highways, or other roads.

1. Select **Where To?** > **Intersections**.
2. Follow the on-screen instructions to enter street information.
3. Select the intersection.

Finding a Location Using Coordinates

You can find a location using latitude and longitude coordinates.

1. Select **Where To?** > **Coordinates**.
2. If necessary, select 🔧, and change the coordinate format or datum.
3. Enter the latitude and longitude coordinates.
4. Select **View on Map**.

Parking

Your dēzl device includes detailed parking data, which can help you find nearby parking based on the likelihood of available parking spots, type of parking area, price, or accepted payment methods.

NOTE: Detailed parking data is not available in all areas or for all parking locations.

Finding Truck Parking

1. Select **Where To?** > **Truck Locations** > **Parking**.
2. If necessary, select **High Capacity Only** to filter locations by parking capacity.
3. Select a parking location.
4. Select **Go!**.

Finding Truck Parking in Europe

1. Select **Where To?** > **Truck Parking Europe**.
2. If necessary, select **Search Filters**, select one or more attributes, and select **Search**.
3. Select a parking location.
4. Select **Go!**.

Finding Parking Near Your Current Location

1. Select **Where To?** > **Parking**.
2. Select **Filter Parking**, and select one or more categories to filter parking by availability, type, price, or payment methods (optional).

   NOTE: Detailed parking data is not available in all areas or for all parking locations.
3. Select a parking location.
4. Select **Go!**.

Finding Parking Near a Specified Location

NOTE: This feature is available only when you are using the car vehicle profile.

1. Select **Where To?**.
2. Search for a location.
3. From the location search results, select a location.
4. Select Ⓟ.

   A list of parking areas near the selected location appears.
5. Select **Filter Parking**, and select one or more categories to filter parking by availability, type, price, or payment methods (optional).

   NOTE: Detailed parking data is not available in all areas or for all parking locations.
6. Select a parking location.
7. Select **Go!**.

Understanding Parking Colors and Symbols

Parking locations that include detailed parking data are color-coded to show the likelihood of finding parking. Symbols indicate the type of parking available (street or lot), relative pricing information, and payment type.

You can view the legend for these colors and symbols on the device.

From the parking search results, select ⓘ.

Viewing Recently Found Locations

Your device stores a history of the last 50 locations you have found.

Select **Where To?** > **Recent**.

Clearing the List of Recently Found Locations

Select **Where To?** > **Recent** > ☰ > **Clear** > **Yes**.

Viewing Current Location Information

You can use the Where Am I? page to view information about your current location. This feature is helpful if you need to tell emergency personnel your location.

From the map, select the vehicle.

Finding Emergency Services and Fuel

You can use the Where Am I? page to find the nearest hospitals, police stations, and fuel stations.

1. From the map, select the vehicle.
2. Select **Hospitals**, **Police Stations**, **Fuel**, or **Roadside Assist.**.

   NOTE: Some service categories are not available in all areas.

   NOTE: When a truck vehicle profile is active, an option for truck stops appears instead of fuel.

   A list of locations for the selected service appears, with the nearest locations at the top.
3. Select a location.
4. Select an option:
   - To navigate to the location, select **Go!**.
   - To view the phone number and other location details, select ⓘ.

Getting Directions to Your Current Location

If you need to tell another person how to get to your current location, your device can give you a list of directions.

1. From the map, select the vehicle.
2. Select ☰ > **Directions to Me**.
3. Select a starting location.
4. Select **Select**.

Saving Locations

Saving a Location

1. Search for a location (*Finding a Location by Category*, page 4).
2. From the search results, select a location.
3. Select ⓘ > **Save**.
4. Enter a name, and select **Done**.

Saving Your Current Location

1. From the map, select the vehicle icon.
2. Select **Save**.
3. Enter a name, and select **Done**.
4. Select **OK**.

Editing a Saved Location

1. Select **Where To?** > **Saved**.
2. If necessary, select a category.
3. Select a location.
4. Select ⓘ.
5. Select ☰ > **Edit**.
6. Select an option:
   - Select **Name**.
   - Select **Phone Number**.
   - Select **Categories** to assign categories to the saved location.
   - Select **Change Map Symbol** to change the symbol used to mark the saved location on a map.
7. Edit the information.
8. Select **Done**.

Assigning Categories to a Saved Location

You can add custom categories to organize your saved locations.

NOTE: Categories appear in the saved locations menu after you have saved at least 12 locations.

1. Select **Where To?** > **Saved**.
2. Select a location.
3. Select ⓘ.
4. Select ☰ > **Edit** > **Categories**.
5. Enter one or more category names, separated by commas.
6. If necessary, select a suggested category.
7. Select **Done**.

Deleting a Saved Location

NOTE: Deleted locations cannot be recovered.

1. Select **Where To?** > **Saved**.
2. Select ☰ > **Delete Saved Places**.
3. Select the box next to the saved locations to delete, and select **Delete**.

Following a Route

Routes

A route is a path from your current location to one or more destinations.

- The device calculates a recommended route to your destination based on the preferences you set, including the route calculation mode (*Changing the Route Calculation Mode*, page 8) and avoidances (*Avoiding Delays, Tolls, and Areas*, page 9).

- You can start navigating to your destination quickly using the recommended route, or you can select an alternate route (*Starting a Route*, page 7).
- If there are specific roads you need to use or avoid, you can customize the route (*Shaping Your Route*, page 8).
- You can add multiple destinations to a route (*Adding a Location to Your Route*, page 8).

Starting a Route

1. Select **Where To?**, and search for a location (*Finding and Saving Locations*, page 3).
2. Select a location.
3. Select an option:
   - To start navigating using the recommended route, select **Go!**.
   - To choose an alternate route, select ⅄, and select a route.

     Alternate routes appear to the right of the map.
   - To edit the course of the route, select ⅄ > **Edit Route**, and add shaping points to the route (*Shaping Your Route*, page 8).

The device calculates a route to the location and guides you using voice prompts and information on the map (*Your Route on the Map*, page 7). A preview of the major roads in your route appears at the edge of the map for several seconds.

If you need to stop at additional destinations, you can add the locations to your route (*Adding a Location to Your Route*, page 8).

Starting a Route by Using the Map

You can start route by selecting a location from the map.

1. Select **View Map**.
2. Drag and zoom the map to display the area to search.
3. If necessary, select 🔍 to filter the displayed points of interest by category.

   Location markers (🍴 or a blue dot) appear on the map.
4. Select an option:
   - Select a location marker.
   - Select a point, such as a street, intersection, or address location.
5. Select **Go!**.

Going Home

The first time you start a route home, the device prompts you to enter your home location.

1. Select **Where To?** > **Go Home**.
2. If necessary, enter your home location.

Editing Your Home Location

1. Select **Where To?** > ☰ > **Set Home Location**.
2. Enter your home location.

Your Route on the Map

As you travel, the device guides you to your destination using voice prompts and information on the map. Instructions for your next turn or exit, or other actions appear across the top of the map.

①	Next action in the route. Indicates the next turn, exit, or other action and the lane in which you should travel, if available.
②	Distance to the next action.
③	Name of the street or exit associated with the next action.
④	Route highlighted on the map.
⑤	Next action in the route. Arrows on the map indicate the location of upcoming actions.
⑥	Vehicle speed.
⑦	Name of the road on which you are traveling.
⑧	Estimated arrival time. **TIP:** You can touch this field to change the information it shows (*Changing the Map Data Field*, page 11).
⑨	Map tools. Provides tools to show you more information about your route and surroundings.

Active Lane Guidance

As you approach some turns, exits, or interchanges in your route, a detailed simulation of the road appears beside the map, if available. A colored line ① indicates the proper lane for the turn.



Viewing Turns and Directions

While navigating a route, you can view upcoming turns, lane changes, or other directions for your route.

1. From the map, select an option:
   - To view upcoming turns and directions as you navigate, select ⋮ > **Turns**.

     The map tool displays the next several turns or directions beside the map. The list updates automatically as you navigate the route.
   - To view the complete list of turns and directions for the entire route, select the text bar at the top of the map.
2. Select a turn or direction (optional).

   Detailed information appears. An image of the junction may appear for junctions on major roadways, if available.

Viewing the Entire Route on the Map

1. While navigating a route, select anywhere on the map.
2. Select .

Arriving at Your Destination

When you approach your destination, the device provides information to help you complete your route.

- indicates the location of your destination on the map, and a voice prompt announces you are approaching your destination.
- When you approach some destinations, the device automatically suggests parking areas. You can select More to view a full list of suggested parking areas (*Parking Near Your Destination*, page 8).
- When you approach some destinations while using a truck vehicle profile, the device automatically prompts you to find a truck destination such as a loading dock or truck parking. You can select a suggested point on the map, and then select Go! to navigate to that destination.
- When you stop at your destination, the device automatically ends the route. If the device does not detect your arrival automatically, you can select Stop to end your route.

Completing a Truck Route

When you approach some truck destinations, a map tool appears to help you find common truck destinations such as parking areas and loading docks.

1. Select a numbered trucking destination ①.



2. Select **Go!**.

Parking Near Your Destination

Your device can help you find a parking spot near your destination. When you approach some destinations, the device automatically suggests parking areas.

NOTE: This feature should be used only when you are using the car vehicle profile. While using a truck vehicle profile, you can search for truck parking near your destination (*Finding Truck Parking*, page 5).

1. Select an option:
   - When the device suggests parking, select **More** to see all suggested parking areas.

     NOTE: When you select a suggested parking area, the device automatically updates your route.
   - If the device does not suggest parking locations, select **Where To?** > **Categories** > **Parking**, and select > **My Destination**.
2. Select **Filter Parking**, and select one or more categories to filter parking by availability, type, price, or payment methods (optional).

   NOTE: Detailed parking data is not available in all areas or for all parking locations.
3. Select a parking location, and select **Go!**.

The device guides you to the parking area.

Changing Your Active Route

Adding a Location to Your Route

Before you can add a location to your route, you must be navigating a route (*Starting a Route*, page 7).

You can add locations to the middle or end of your route. For example, you can add a fuel station as the next destination in your route.

TIP: To create complex routes with multiple destinations or scheduled stops, you can use the trip planner to plan, schedule, and save a trip (*Planning a Trip*, page 17).

1. From the map, select > **Where To?**.
2. Search for a location (*Finding and Saving Locations*, page 3).
3. Select a location.
4. Select **Go!**.
5. Select an option:
   - To add the location as the next destination in your route, select **Add As Next Stop**.
   - To add the location to the end of your route, select **Add As Last Stop**.
   - To add the location and edit the order of destinations in your route, select **Add to Active Route**.

The device re-calculates the route to include the added location and guides you to the destinations in order.

Shaping Your Route

Before you can shape your route, you must start a route (*Starting a Route*, page 7).

You can manually shape your route to change its course. This allows you to direct the route to use a certain road or go through a certain area without adding a destination to the route.

1. Touch anywhere on the map.
2. Select **Shape Route**.

   TIP: You can select to zoom in on the map and select a more precise location.

   The device enters route shaping mode and recalculates the route to travel through the selected location.
3. Select **Go!**.
4. If necessary, select an option:
   - To add more shaping points to the route, select additional locations on the map.
   - To remove a shaping point, select the shaping point and select **Remove**.

Taking a Detour

You can take a detour for a specified distance along your route or detour around specific roads. This is useful if you encounter construction zones, closed roads, or poor road conditions.

1. From the map, select > **Edit Route**.
2. Select an option:
   - To detour your route for a specific distance, select **Detour by Distance**.
   - To detour around a specific road on the route, select **Detour by Road**.

Changing the Route Calculation Mode

1. Select **Settings** > **Navigation** > **Calculation Mode**.
2. Select an option:
   - Select **Faster Time** to calculate routes that are faster to drive but can be longer in distance.
   - Select **Off Road** to calculate point-to-point routes (without roads).

Stopping the Route

From the map, select ⋮ > **Stop**.

Using Suggested Routes

Before you can use this feature, you must save at least one location and enable the travel history feature (*Device and Privacy Settings*, page 19).

Using the myTrends™ feature, your device predicts your destination based on your travel history, the day of the week, and the time of day. After you have driven to a saved location several times, the location may appear in the navigation bar on the map, along with the estimated time of travel, and traffic information.

Select the navigation bar to view a suggested route to the location.

Avoiding Delays, Tolls, and Areas

Avoiding Traffic Delays on Your Route

Before you can avoid traffic delays, you must be receiving traffic information.

By default, the device optimizes your route to avoid traffic delays automatically. If you have disabled this option in the traffic settings (*Traffic Settings*, page 19), you can view and avoid traffic delays manually.

1. While navigating a route, select ⋮ > **Traffic**.
2. Select **Alternate Route**, if available.
3. Select **Go!**.

Avoiding Toll Roads

Your device can avoid routing you through areas that require tolls, such as toll roads, toll bridges, or congestion areas. The device may still include a toll area in your route if no other reasonable routes are available.

1. Select **Settings** > **Navigation**.
2. Select an option:

   NOTE: The menu changes based on your area and the map data on your device.

   - Select **Toll Roads**.
   - Select **Tolls and Fees** > **Toll Roads**.
3. Select an option:
   - To be asked each time before routing through a toll area, select **Always Ask**.
   - To always avoid tolls, select **Avoid**.
   - To always allow tolls, select **Allow**.
4. Select **Save**.

Avoiding Toll Stickers

If the map data on your device contains detailed toll sticker information, you can avoid or allow roads that require toll stickers for each country.

NOTE: This feature is not available in all areas.

1. Select **Settings** > **Navigation** > **Tolls and Fees** > **Toll Stickers**.
2. Select a country.
3. Select an option:
   - To be asked each time before routing through an area that requires toll stickers, select **Always Ask**.
   - To always avoid roads that require toll stickers, select **Avoid**.
   - To always allow roads that require toll stickers, select **Allow**.
4. Select **Save**.

Avoiding Road Features

1. Select **Settings** > **Navigation** > **Avoidances**.
2. Select the road features to avoid on your routes, and select **Save**.

Avoiding Environmental Zones

Your device can avoid areas with environmental or emissions restrictions that may apply to your vehicle.

1. Select **Settings** > **Navigation** > **Environmental Zones**.
2. Select an option:
   - To be asked each time before routing through an environmental zone, select **Always Ask**.
   - To always avoid environmental zones, select **Avoid**.
   - To always allow environmental zones, select **Allow**.
3. Select **Save**.

Custom Avoidances

Custom avoidances allow you select specific areas or sections of road to avoid. When the device calculates a route, it avoids these areas and roads unless no other reasonable route is available.

Avoiding a Road

1. Select **Settings** > **Navigation** > **Custom Avoidances**.
2. If necessary, select **Add Avoidance**.
3. Select **Add Avoid Road**.
4. Select the starting point of the section of road to avoid, and select **Next**.
5. Select the ending point of the road section, and select **Next**.
6. Select **Done**.

Avoiding an Area

1. Select **Settings** > **Navigation** > **Custom Avoidances**.
2. If necessary, select **Add Avoidance**.
3. Select **Add Avoid Area**.
4. Select the upper-left corner of the area to avoid, and select **Next**.
5. Select the lower-right corner of the area to avoid, and select **Next**.

   The selected area is shaded on the map.
6. Select **Done**.

Disabling a Custom Avoidance

You can disable a custom avoidance without deleting it.

1. Select **Settings** > **Navigation** > **Custom Avoidances**.
2. Select an avoidance.
3. Select ☰ > **Disable**.

Deleting Custom Avoidances

1. Select **Settings** > **Navigation** > **Custom Avoidances** > 🗑.
2. Select an option:
   - To delete all custom avoidances, select **Select All** > **Delete**.
   - To delete one custom avoidance, select the avoidance, and select **Delete**.

Using the Map

You can use the map to navigate a route (*Your Route on the Map*, page 7) or to view a map of your surroundings when no route is active.

1. Select **View Map**.
2. Touch anywhere on the map.

3 Select an option:
- Drag the map to pan left, right, up, or down.
- To zoom in or out, select + or −.
- To switch between North Up and 3-D views, select ▲.
- To filter the displayed points of interest by category, select 🔍.
- To start a route, select a location on the map, and select **Go!** (*Starting a Route by Using the Map*, page 7).

Map Tools

Map tools provide quick access to information and device functions while you view the map. When you activate a map tool, it appears in a panel at the edge of the map.

Stop: Stops navigation of the active route.

Edit Route: Allows you to take a detour or skip locations in your route (*Changing Your Active Route*, page 8).

Mute: Mutes the device audio.

Cities Ahead: Shows upcoming cities and services along your active route or along a highway (*Cities Ahead*, page 10).

Up Ahead: Shows upcoming locations along the route or the road on which you are traveling (*Up Ahead*, page 10).

Elevation: Displays elevation changes ahead.

Traffic: Displays traffic conditions along your route or in your area (*Viewing Upcoming Traffic*, page 11). This feature is not available in all areas or for all device models.

Trip Data: Displays customizable trip data, such as speed or mileage (*Viewing Trip Data from the Map*, page 10).

Turns: Displays a list of upcoming turns in your route (*Viewing Turns and Directions*, page 7).

Phone: Displays a list of recent phone calls from your connected phone, and displays in-call options while a phone call is active (*Using In-Call Options*, page 13).

Weather: Displays weather conditions for your area.

photoLive: Displays live traffic cameras from your photoLive subscription (*photoLive Traffic Cameras*, page 18).

Report Safety Camera: Allows you to report a speed or red light camera. This tool is available only when you have speed or red light camera data on your device and you have an active connection to the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

Break Planner: Displays break reminders and suggested stops.

Garmin eLog: Displays hours of service information from the Garmin eLog app. Allows you to change duty status while you are not driving.

Viewing a Map Tool

1 From the map, select ⋮.
2 Select a map tool.

The map tool appears in a panel at the edge of the map.

3 When you are done using the map tool, select ✕.

Up Ahead

The Up Ahead tool provides information about upcoming locations along your route or the road on which you are traveling. You can view upcoming points of interest by category, such as restaurants, fuel stations, or rest areas.

You can customize three categories to show in the Up Ahead tool.

Viewing Upcoming Locations

1 From the map, select ⋮ > **Up Ahead**.

While you are traveling, the map tool shows the next location along your road or route in each of the three categories.

While you are not traveling, the map tool shows the three category names.

2 Select an option:
- If the map tool shows categories, select a category to view a list of nearby locations in that category.
- If the map tool shows upcoming locations, select a location to view location details or start a route to the location.

Customizing the Up Ahead Categories

You can change the location categories that appear in the Up Ahead tool.

1 From the map, select ⋮ > **Up Ahead**.
2 Select a category.
3 Select 🔧.
4 Select an option:
- To move a category up or down in the list, select and drag the arrow next to the category name.
- To change a category, select the category.
- To create a custom category, select a category, select **Custom Search**, and enter the name of a business or category.

5 Select **Save**.

Cities Ahead

While you are traveling on a highway or navigating a route that includes a highway, the Cities Ahead tool provides information about upcoming cities along the highway. For each city, the map tool shows the distance to the highway exit and the services available, similar to the information on highway road signs.

Viewing Upcoming Cities and Exit Services

1 From the map, select ⋮ > **Cities Ahead**.

While you are traveling along a highway or an active route, the map tool shows information about upcoming cities and exits.

2 Select a city.

The device shows a list of points of interest located at the selected city exit, such as fuel stations, lodging, or restaurants.

3 Select a location, and select **Go!** to start navigating.

Trip Information

Viewing Trip Data from the Map

From the map, select ⋮ > **Trip Data**.

Viewing Customized Trip Information on the Map

You can use the trip data map tool to show customized trip information on the map.

1 From the map, select ⋮ > **Trip Data**.
2 Select an option:



- Select a data field in the trip data tool ①, and select the information to show in the field.
- Select the customizable map data field ②, and select the information to show in the field.

Viewing the Trip Information Page

The trip information page displays your speed and provides statistics about your trip.

From the map, select **Speed**.

Resetting Trip Information

1. From the map, select **Speed**.
2. Select ☰ > **Reset Field(s)**.
3. Select an option:
   - When not navigating a route, select **Select All** to reset every data field except the speedometer, on the first page.
   - Select **Reset Overall Data** to reset the information on the trip computer.
   - Select **Reset Max. Speed** to reset the maximum speed.
   - Select **Reset Trip B** to reset the odometer.

Viewing Upcoming Traffic

Before you can use this feature, your device must be receiving traffic data (*Traffic*, page 13).

You can view traffic incidents coming up along your route or along the road on which you are traveling.

1. While navigating a route, select ⋮ > **Traffic**.

   The nearest upcoming traffic incident appears in a panel on the right side of the map.
2. Select the traffic incident to view additional details.

Viewing Traffic on the Map

The traffic map shows color-coded traffic flow and delays on nearby roads.

1. From the main menu, select **Apps** > **Traffic**.
2. If necessary, select ☰ > **Legend** to view the legend for the traffic map.

Searching for Traffic Incidents

1. From the main menu, select **Apps** > **Traffic**.
2. Select ☰ > **Incidents**.
3. Select an item in the list.
4. If there is more than one incident, use the arrows to view additional incidents.

Customizing the Map

Customizing the Map Layers

You can customize which data appear on the map, such as icons for points of interest and road conditions.

1. Select **Settings** > **Map & Vehicle** > **Map Layers**.
2. Select the check box next to each layer you want to show on the map.

Changing the Map Data Field

1. From the map, select a data field.

   NOTE: You cannot customize Speed.
2. Select a type of data to display.

Changing the Map Perspective

1. Select **Settings** > **Map & Vehicle** > **Driving Map View**.
2. Select an option:
   - Select **Track Up** to display the map in two dimensions (2-D), with your direction of travel at the top.
   - Select **North Up** to display the map in 2-D with north at the top.
   - Select **3-D** to display the map in three dimensions.

Live Services, Traffic, and Smartphone Features

The Garmin Drive app allows your device to receive smart notifications and live information, such as live traffic data and weather information.

Live traffic data: Sends real-time traffic data to your device, such as traffic incidents and delays, construction zones, and road closings (*Traffic*, page 13).

Weather information: Sends real-time weather forecasts, road conditions, and weather radar to your device (*Viewing the Weather Forecast*, page 16).

Smart Notifications: Displays phone notifications and messages on your device. This feature is not available for all languages.

Hands-Free calling: Allows you to place and receive phone calls using your device, and allows you to use the device as a hands-free speaker phone. If the selected language supports the voice command feature, you can place calls using voice commands.

Send locations to device: Allows you to send locations from your smartphone to your navigation device.

Foursquare check in: Allows you to check in to Foursquare locations using your navigation device (*Checking in with Foursquare*, page 5).

Pairing with Your Smartphone

You can pair your dēzl device with your smartphone and the Garmin Drive app to enable additional features and access live information (*Live Services, Traffic, and Smartphone Features*, page 11) .

1. From the app store on your smartphone, install the Garmin Drive app.
2. Turn on your dēzl device, and place the device and your smartphone within 3 m (10 ft.) of each other.
3. On your phone, open the Garmin Drive app.
4. Follow the on-screen instructions to sign in to a Garmin account and complete the pairing and setup process.

The main app dashboard appears. After the devices are paired, they connect automatically when they are turned on and within range.

Disabling Bluetooth Features (Android™)

By default, all compatible Bluetooth features are enabled when you pair your phone. You can disable specific Bluetooth features and remain connected to the other features.

1. Select **Settings** > **Wireless Networks**.
2. Select an option:
   - To disable all Bluetooth features, clear the Bluetooth check box.
   - To disable only hands-free calling, select the phone name and clear the **Phone calls** check box.

Showing or Hiding App Notifications (Android)

You can use the Garmin Drive app to customize which types of smartphone notifications appear on your dēzl device.

1. On your phone, open the Garmin Drive app.
2. Select ⚙ > **Smart Notifications**.

   A list of your smartphone apps appears.
3. Select the toggle switch next to an app to enable or disable notifications for the app.

Disabling Bluetooth Features (iPhone®)

By default, all compatible Bluetooth features are enabled when you pair your phone. You can disable specific Bluetooth features and remain connected to the other features.

1. Select **Settings** > **Wireless Networks**.
2. Select an option:
   - To disable hands-free calling, select the phone name, and clear the **Phone calls** check box.

     TIP: appears colored next to the phone name used for hands-free calling.
   - To disable Garmin Drive app data and smartphone notifications, select **iOS Services**, and clear the **iOS Services** check box.

     TIP: and appear colored when the services are active.

Showing or Hiding Notification Categories (iPhone)

You can filter the notifications shown on your device by showing or hiding categories.

1. Select **Settings** > **Wireless Networks**.
2. Select **iOS Services**.

   TIP: and appear colored when the services are active.
3. Select **Smart Notifications**.
4. Select the check box next to each notification to show.

Bluetooth Feature Status Icons

Status icons appear in the Bluetooth settings next to each paired device.

Select **Settings** > **Wireless Networks**.

- A gray icon indicates the feature is disabled or disconnected for that device.
- A colored icon indicates the feature is connected and active for that device.

	Hands-free calling
	Smart notifications
	Garmin Drive features and services

Smart Notifications

While your device is connected to the Garmin Drive app, you can view notifications from your smartphone on your dēzl device, such as text messages, incoming calls, and calendar appointments.

NOTE: You may need to wait a few minutes to receive notifications on your navigation device after it connects to the Garmin Drive app. appears colored in the Bluetooth settings when smart notifications are connected and active (*Bluetooth Feature Status Icons*, page 12).

Receiving Notifications

⚠ WARNING

Do not read or reply to notifications while driving.

Before you can use this feature, your device must be connected to a supported phone running the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

From most pages, a popup appears when the device receives a notification from your smartphone. If the device is moving, you must verify you are a passenger and not the driver before you can view notifications.

NOTE: If you are viewing the map, notifications appear in a map tool.

- To ignore a notification, select **OK**.

  The popup closes, but the notification remains active on your phone.
- To view a notification, select **View**.
- To listen to the notification, select **View** > **Play**.

  The device reads the notification using text-to-speech technology. This feature is not available for all languages.
- To perform additional actions, such as dismissing the notification from your phone, select **View**, and select an option.

  NOTE: Additional actions are available for only some notification types and must be supported by the app generating the notification.

Receiving Notifications while Viewing the Map

⚠ WARNING

Do not read or reply to notifications while driving.

Before you can use this feature, your device must be connected to a supported phone running the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

When you are viewing the map, new notifications appear in a map tool at the edge of the screen. If the device is moving, you must verify you are a passenger and not the driver before you can view notifications.

- To ignore a notification, select ✕, or wait for popup to expire.

  The popup closes, but the notification remains active on your phone.
- To view a notification, select the notification text.
- To listen to the notification, select **Play Message**.

  The device reads the notification using text-to-speech technology. This feature is not available for all languages.
- To listen to the notification using a voice command, say **Play Message**.

  NOTE: This option is available only when the selected language supports the voice command feature and appears in the map tool.
- To perform additional actions, such as dismissing the notification from your phone, select **View**, and select an option.

  NOTE: Additional actions are available for only some notification types and must be supported by the app generating the notification.

Viewing the List of Notifications

You can view a list of all active notifications.

1. Select **Apps** > **Smart Notifications**.

   The list of notifications appears. Unread notifications appear black, and previously read notifications appear gray.
2. Select an option:
   - To view a notification, select the notification description.
   - To listen to a notification, select ▶.

     The device reads the notification using text-to-speech technology. This feature is not available for all languages.

Going to an Address or Location Using the Garmin Drive App

You can use the Garmin Drive app to search for an address, business, or point of interest, and send it to your dēzl device for navigation.

1. From the Garmin Drive app, select **Where To?**.
2. Select an option:
   - To search for an address near you, enter the house number and street name.
   - To search for an address in another city, enter the house number, street name, city, and state.

- To search for a business name, enter all or part of the name.
- To search for a city, enter the city and state.

As you type, suggestions appear below the search field.

3 Select a suggested search result.

The app displays the location on a map.

4 Select **Go!** to start a route.

The dēzl device starts navigating to the selected location, and the location is added to your recent searches in the Where To? menu.

Hands-Free Calling

NOTE: While most phones are supported and can be used, it cannot be guaranteed that a particular phone can be used. All features may not be available for your phone.

Using Bluetooth wireless technology, your device can connect to your mobile phone to become a hands-free device (*Live Services, Traffic, and Smartphone Features*, page 11). While connected, you can place or receive calls using your device.

Placing a Call

Dialing a Number

1 Select **Apps** > **Phone** > **Dial**.

2 Enter the number.

3 Select **Dial**.

Calling a Contact in Your Phone Book

Your phone book is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the phone book to be available. Some phones do not support this feature.

1 Select **Apps** > **Phone** > **Phone Book**.

2 Select a contact.

3 Select **Call**.

Calling a Location

1 Select **Apps** > **Phone** > **Browse Categories**.

2 Select a point of interest.

3 Select ☰ > **Call**.

Placing a Call Using Voice Dial

1 Select **Apps** > **Phone** > **Voice Dial**.

2 Listen for the voice prompt.

3 Say **Call**, and say the contact name, phone number, or location you want to call.

Receiving a Call

When you receive a call, select **Answer** or **Ignore**.

Using the Call History

Your call history is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the call history to be available. Some phones do not support this feature.

1 Select **Apps** > **Phone** > **Call History**.

2 Select a category.

A list of calls appears, with the most recent calls at the top.

3 Select a call.

Using In-Call Options

In-call options appear on the map when you answer a call. Some options may not be compatible with your phone.

TIP: If you close the in-call options page, you can open it again by selecting ☎ from the main menu. You can also select ⋮ > **Phone** from the map.

- To set up a conference call, select the caller ID, and select **Add Call**.
- To transfer audio to your phone, select **Handset**.

  TIP: You can use this feature if you want to disconnect the Bluetooth connection and remain on the call, or if you need privacy.
- To use the dial pad, select the caller ID, and select **Keypad**.

  TIP: You can use this feature to use automated systems, such as voice mail.
- To mute the microphone, select **Mute**.
- To hang up, select **End**.

Saving a Home Phone Number

TIP: After you save a home number, you can edit the home number by editing “Home” in your list of saved locations (*Editing a Saved Location*, page 6).

1 Select **Apps** > **Phone** > ☰ > **Set Home Number**.

2 Enter your phone number.

3 Select **Done**.

Calling Home

Before you can call home, you must enter a phone number for your home location.

Select **Apps** > **Phone** > **Call Home**.

Deleting a Paired Phone

You can delete a paired phone to prevent it from automatically connecting to your device in the future.

1 Select **Settings** > **Wireless Networks**.

2 Select the phone, and select **Forget Device**.

Traffic

NOTICE

Garmin is not responsible for the accuracy or timeliness of the traffic information.

Your device can provide information about traffic on the road ahead or on your route. You can set your device to avoid traffic when calculating routes, and to find a new route to your destination if a large traffic delay occurs on your active route (*Traffic Settings*, page 19). The traffic map allows you to browse the map for traffic delays in your area.

To provide traffic information, your device must be receiving traffic data.

- All product models can receive subscription-free traffic data using the Garmin Drive app (*Receiving Traffic Data Using Your Smartphone*, page 13).

Traffic data is not available in all areas. For information about traffic coverage areas, go to garmin.com/traffic.

Receiving Traffic Data Using Your Smartphone

Your device can receive subscription-free traffic data while connected to a smartphone running the Garmin Drive app.

1 Connect your device to the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

2 On your dēzl device, select **Settings** > **Traffic**, and verify the **Traffic** check box is selected.

Receiving Traffic Data Using a Traffic Receiver

NOTICE

Heated (metallized) windshields could degrade the performance of the traffic receiver.

A traffic receiver receives traffic data from an over-the-air broadcast signal, where available. To receive over-the-air traffic data, the device must be connected to vehicle power using a traffic-compatible power cable. A traffic receiver is included with some product models (*Traffic*, page 13). .

Traffic data is not available in all areas. For information about traffic coverage areas, go to garmin.com/traffic.

Connect the device to vehicle power using the traffic compatible power cable (*Mounting and Powering the dēzl Device in Your Vehicle*, page 1).

If your product model includes traffic data, the vehicle power cable included with your device is traffic compatible.

When you are within a traffic coverage area, your device can display traffic information and help you avoid traffic delays.

Traffic Receiver Subscriptions

A regional traffic data subscription is included with most traffic receivers. You can add subscriptions for additional regions to your traffic receiver. For more information, go to garmin.com/traffic.

Viewing Traffic Subscriptions

Select **Settings** > **Traffic** > **Subscriptions**.

Adding a Subscription

You can purchase traffic subscriptions for other regions or countries.

1. Select **Settings** > **Traffic**.
2. Select **Subscriptions** > ✚.
3. Write down the FM traffic receiver unit ID.
4. Go to www.garmin.com/fmtraffic to purchase a subscription and get a 25-character code.

   The traffic subscription code cannot be reused. You must obtain a new code each time you renew your service. If you own multiple FM traffic receivers, you must obtain a new code for each receiver.
5. Select **Next** on the device.
6. Enter the code.
7. Select **Done**.

Enabling Traffic

You can enable or disable traffic data.

1. Select **Settings** > **Traffic**.
2. Select the **Traffic** check box.

Viewing Traffic on the Map

The traffic map shows color-coded traffic flow and delays on nearby roads.

1. From the main menu, select **Apps** > **Traffic**.
2. If necessary, select ☰ > **Legend** to view the legend for the traffic map.

Searching for Traffic Incidents

1. From the main menu, select **Apps** > **Traffic**.
2. Select ☰ > **Incidents**.
3. Select an item in the list.
4. If there is more than one incident, use the arrows to view additional incidents.

Vehicle and Driver Tools

Break Planning

NOTICE

This device by itself is NOT an approved substitute for logbook recording requirements under Federal Motor Carrier Safety Administration (FMCSA) regulations. Drivers should comply with all applicable federal and state hours-of-service requirements. When integrated with a Garmin eLog compliant Electronic Logging Device (ELD), this device enables a motor carrier to comply with hours of service logging and break requirements. For more information, or to purchase a Garmin eLog device, go to garmin.com/elog.

When the break planning feature is enabled, the device notifies you one hour before suggested break times and drive hour limits and suggests break locations on your route. You can use this feature to keep track of your working hours, which may help you comply with safety regulations.

NOTE: Break planning features are not available when using the car vehicle profile.

Taking a Suggested Break

When it is time for a break, the device notifies you and displays suggested break location POIs along your route.

Select a POI from the list of suggested break locations.

The device adds the break location as the next destination on your route.

Starting the Break Timer

The break timer starts automatically when the vehicle is moving at least 8 kph (5 mph) for 30 seconds. You can start the timer manually at any time.

1. From the map, select ⋮ > **Break Planner**.
2. Select **Start Timer**.

Pausing and Resetting the Break Timer

The break timer pauses automatically when the vehicle stops for three minutes or longer. You can pause the timer manually for brief stops, such as parking or stopping at a truck stop. At the end of your drive, you can manually reset the timer.

1. Select **Stop Timer**.
2. Select an option:
   - To pause the timer, select **Pause**.
   - To stop and reset the timer, select **Reset**.

Adjusting Drive Hours

You can adjust your total hours driven to more closely match your hours of service records.

1. While using the break planner feature, select **Total Hours Driven**.
2. Enter the total hours driven.
3. Select **Save**.

Adjusting the Daily Driving Limit

You can adjust the daily driving limit to correspond with legal requirements in your area.

NOTE: This feature is not available in all areas.

1. While using the break planner feature, select **Daily Hours Driven**.
2. Select the daily driving limit for your area.
3. Select **Save**.

Garmin eLog

The Garmin eLog adapter enables a motor carrier to comply with hours of service logging and break requirements. When a

Garmin eLog adapter is paired with your compatible mobile device, you can view hours of service information on your dēzl device. The Garmin eLog adapter is not available in all areas. For more information, or to purchase a Garmin eLog adapter, go to garmin.com/elog.

NOTE: Garmin eLog features are not available when using the car vehicle profile.

Setting Up Garmin eLog Features On Your dēzl Device

1. Pair your Garmin eLog adapter with the Garmin eLog app on your mobile device (*Setting Up Your Garmin eLog Device*, page 15).
2. Pair your dēzl device with your compatible mobile device (*Live Services, Traffic, and Smartphone Features*, page 11).
3. Enable the Garmin eLog app to pair with a dēzl device (*Enabling the Garmin eLog App to Pair with a dēzl Device*, page 15).
4. If necessary, enable the Garmin eLog connection on your dēzl device (*Enabling or Disabling the Garmin eLog Connection on Your dēzl Device*, page 15).

Setting Up Your Garmin eLog Device

You must set up and pair your Garmin eLog adapter with the Garmin eLog app in order to use the device.

1. From the app store on your mobile device, install and open the Garmin eLog app.
2. On your mobile device, follow the on-screen instructions to set up and configure the Garmin eLog system.

   NOTE: Until you complete the setup process, the device has limited functionality.

Enabling the Garmin eLog App to Pair with a dēzl Device

1. From the Garmin eLog app, log in to a driver profile.
2. Select **Settings** > **Pair to Nearby Garmin dēzl**.

Enabling or Disabling the Garmin eLog Connection on Your dēzl Device

1. From your dēzl device, select **Settings** > **Wireless Networks**.
2. Select the name of your paired mobile device.
3. Select or clear the **Garmin eLog Adapter** check box.

Viewing Garmin eLog Information on Your dēzl Device

Before you can view Garmin eLog information on your dēzl device, you must complete the setup process (*Setting Up Garmin eLog Features On Your dēzl Device*, page 15).

As you drive your vehicle, the device displays your duty status and total drive hours in the Garmin eLog map tool.

Select a field to view a summary of remaining drive hours.

Viewing Garmin eLog Diagnostic and Malfunction Events

When the Garmin eLog device detects a diagnostic or malfunction event, it displays a notification on the device screen.

Select the diagnostic or malfunction notification to view details about the event.

NOTE: You can view additional information about diagnostic and malfunction events in the Garmin eLog app.

IFTA

NOTE: This feature is not available in all areas.

Before you can use this feature, a truck vehicle profile must be active.

You can record data needed for International Fuel Tax Agreement documentation (IFTA), such as fuel-purchase data and miles driven.

Entering Fuel Data

1. Select **Apps** > **IFTA** > **At the Pump**.
2. Enter the fuel price per gallon.
3. Select the **Fuel Used** field.
4. Enter the amount of fuel purchased.
5. If necessary, select the fuel type:
   - To record the amount in liters, select **Gallons** > **Liters** > **Save**.
   - To record the amount in gallons, select **Liters** > **Gallons** > **Save**.
6. If necessary, select the **Tax Included** check box.
7. Select **Next**.
8. Select an option to record the fuel station where you refueled:
   - Select a nearby fuel station from the list.
   - Select the text field, and enter the fuel station name and address.
9. Select the fuel purchaser.

Editing Fuel Data

1. Select **Apps** > **IFTA** > **Fuel Journals**.
2. If necessary, select a vehicle profile.
3. If necessary, select a quarter.
4. Select a fuel record.
5. Select an option:
   - Select a field to edit the information.
   - Select to delete the record.

Viewing and Exporting a Jurisdiction Summary

The jurisdiction summary lists data for each state or province in which your vehicle has operated during each quarter. The jurisdiction summary is available in some areas.

1. Select **Apps** > **IFTA** > **Jurisdiction Summary**.
2. If necessary, select a truck.
3. If necessary, select a quarter.
4. Select > **Export** > **OK** to export a jurisdiction summary.

   The device exports the summary to a .csv file and stores it in the Reports folder on the device.

Editing and Exporting Trip Reports

1. From the main menu, select **Apps** > **IFTA** > **Trip Reports**.
2. If necessary, select a truck.
3. If necessary, select a quarter.
4. Select a report.
5. Select an option:
   - Select > **Delete**, and select the check box to delete a report.
   - Select > **Combine**, and select the check boxes to combine reports.
   - Select > **Export** > **OK**. The device exports the report to a .csv file and stores it in the **Reports** folder on the device.

Viewing Exported Jurisdiction Summaries and Trip Reports

NOTICE

If you do not know the purpose of a file, do not delete it. Your device memory contains important system files that should not be deleted.

1. Connect the device to your computer.
2. From the file browser on your computer, browse to the internal device storage, and open the **Reports** folder.

3 Open the **IFTA** folder.
4 Open the .csv file.

Logging Service History

You can log the date and odometer reading when service or maintenance is performed on your vehicle. The device provides several service categories, and you can add custom categories (*Adding Service Categories*, page 16).

1 Select **Apps** > **Service History**.
2 Select a service category.
3 Select **Add Record**.
4 Enter the odometer reading, and select **Next**.
5 Enter a comment (optional).
6 Select **Done**.

Adding Service Categories

1 Select **Apps** > **Service History**.
2 Select ☰ > **Add Category**.
3 Enter a category name, and select **Done**.

Deleting Service Categories

When you delete a service category, all service records in the category are also deleted.

1 Select **Apps** > **Service History**.
2 Select ☰ > **Delete Categories**.
3 Select the service categories to delete.
4 Select **Delete**.

Renaming Service Categories

1 Select **Apps** > **Service History**.
2 Select the category to be renamed.
3 Select ☰ > **Rename Category**.
4 Enter a name, and select **Done**.

Deleting Service Records

1 Select **Apps** > **Service History**.
2 Select a service category.
3 Select ☰ > **Delete Records**.
4 Select the service records to be deleted.
5 Select **Delete**.

Editing a Service Record

You can edit the comment, odometer reading, and date of a service record.

1 Select **Apps** > **Service History**.
2 Select a category.
3 Select a field.
4 Enter the new information, and select **Done**.

Voice Command

NOTE: Voice command is not available for all languages and regions, and may not be available on all models.

NOTE: Voice Activated Navigation may not achieve desired performance when in a noisy environment.

Voice command allows you to use your device by saying words and commands. The voice command menu provides voice prompts and a list of available commands.

Tips for Speaking to the Device

- Speak in a clear voice directed at the device.
- Start each request with *OK, Garmin*.
- Reduce background noise, such as voices or the radio, to help the device interpret your commands more accurately.
- Respond to voice prompts from the device as needed.
- If you do not receive a useful response, try rephrasing your request.
- If the device does not respond to your requests, verify it is not placed near a speaker or air vent, which can produce noise that interferes with the microphone.

Launching Garmin Voice-Activated Navigation

Garmin voice-activated navigation allows you to use plain language spoken requests to search for locations and addresses, start routes with turn-by-turn directions, place hands-free phone calls, and more.

- Say *OK, Garmin*, and make a spoken request.

  For example, you can say phrases like these:
  - *OK, Garmin, take me home.*
  - *OK, Garmin, where's the library?*

Checking Your Arrival Time

While a route is active, you can say a phrases to check your estimated time of arrival at your destination.

Say *OK, Garmin, what time will we arrive?*.

Placing a Phone Call Using Your Voice

You can use a voice command to call to a contact from the phone book of your paired smartphone.

Say *OK, Garmin, call*, and say the contact name.

For example, you can say *OK, Garmin, call Mom.*.

Changing Device Settings Using Your Voice

You can say phrases like these to set the volume or brightness to a value from 0 to 10.

- *OK, Garmin, increase the volume.*
- *OK, Garmin, set the volume to 0.*
- *OK, Garmin, set the volume to 9.*
- *OK, Garmin, decrease the brightness.*
- *OK, Garmin, set the brightness to 5.*

Using the Apps

Viewing the Owner's Manual on Your Device

You can view the complete owner's manual on the device screen in many languages.

1 Select **Apps** > **Owner's Manual**.

The owner's manual appears in the same language as the software text (*Language and Keyboard Settings*, page 19).

2 Select 🔍 to search the owner's manual (optional).

Viewing the Weather Forecast

Before you can use this feature, your device must be receiving weather data. You can connect your device to the Garmin Drive app to receive weather data (*Live Services, Traffic, and Smartphone Features*, page 11).

1 Select **Apps** > **Weather**.

The device shows the current weather conditions and a forecast for the next several days.

2 Select a day.

The detailed forecast for that day appears.

Viewing Weather Near a Different City

1. Select **Apps** > **Weather** > **Current Location**.
2. Select an option:
   - To view weather for a favorite city, select a city in the list.
   - To add a favorite city, select **Add City**, and enter a city name.

Viewing the Weather Radar

Before you can use this feature, your device must be connected to a supported phone running the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

1. Select **Apps** > **Weather Radar**.
2. Select ▶ to animate the radar map.

Viewing Weather Alerts

Before you can use this feature, your device must be connected to a supported phone running the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

NOTE: This feature is not available in all areas.

While you are traveling with your device, weather alerts may appear on the map. You can also view a map of weather alerts near your current location or near a selected city.

1. Select **Apps** > **Weather**.
2. If necessary, select a city.
3. Select ☰ > **Weather Alerts**.

Checking Road Conditions

Before you can use this feature, your device must be connected to a supported phone running the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

You can view weather-related road conditions for the roads in your area, on your route, or in another city.

1. Select **Apps** > **Weather**.
2. If necessary, select a city.
3. Select ☰ > **Road Conditions**.

Trip Planner

You can use the trip planner to create and save a trip, which you can navigate later. This can be useful for planning a delivery route, a vacation, or a road trip. You can edit a saved trip to further customize it, including reordering locations, optimizing the order of stops, adding suggested attractions, and adding shaping points.

You can also use the trip planner to edit and save your active route.

Planning a Trip

A trip can include many destinations, and it must include at least a starting location and one destination. The starting location is the location from which you plan to start your trip. If you start navigating the trip from a different location, the device gives you the option to route to your starting location first. For a round trip, the starting location and final destination can be the same.

1. Select **Apps** > **Trip Planner** > **New Trip**.
2. Select **Select Start Location**.
3. Choose a location for your starting point, and select **Select**.
4. Select **Select Destination**.
5. Choose a location for a destination, and select **Select**.
6. Select **Add Location** to add more locations (optional).
7. After you have added all the necessary locations, select **Next** > **Save**.
8. Enter a name, and select **Done**.

Editing and Reordering Locations in a Trip

1. Select **Apps** > **Trip Planner** > **Saved Trips**.
2. Select a saved trip.
3. Select a location.
4. Select an option:
   - To move the location up or down, select ⇵, and drag the location to a new position in the trip.
   - To add a new location after the selected location, select ⊕.
   - To remove the location, select 🗑.

Optimizing the Order of Destinations in a Trip

The device can automatically optimize the order of destinations in your trip to create a shorter, more efficient route. The starting location and final destination are not changed when you optimize the order.

While editing a trip, select 🔧 > **Optimize Order**.

Discovering Attractions Along Your Trip

The device can suggest interesting or popular attractions to add to your trip.

1. While editing a trip, select 🔧 > **Suggest Attractions**.
2. Select an attraction to view more information.
3. Select **Select** to add the attraction to your trip.

Changing Routing Options for a Trip

You can customize how the device calculates the route when you start your trip.

1. Select **Apps** > **Trip Planner** > **Saved Trips**.
2. Select a saved trip.
3. Select the vehicle profile icon, and select the vehicle you plan to use while navigating the trip (optional).
4. Select 🔧.
5. Select an option:
   - To add shaping points to your trip, select **Shape Route**, and follow the on-screen instructions (*Shaping Your Route*, page 8).
   - To change the calculation mode for the trip, select **Route Preference** (*Changing the Route Calculation Mode*, page 8).

Navigating to a Saved Trip

Before you can start navigating a saved trip, the active vehicle profile on the device must match the selected vehicle profile for the trip (*Changing Routing Options for a Trip*, page 17). If it does not match, the device prompts you to change the vehicle profile before you can start the trip (*Switching the Vehicle Profile*, page 2).

1. Select **Apps** > **Trip Planner** > **Saved Trips**.
2. Select a saved trip.
3. Select **Go!**.
4. Select the first location to navigate to, and select **Start**.

   The device calculates a route from your current location to the selected location, and then it guides you to the remaining trip destinations in order.

Editing and Saving Your Active Route

If a route is active, you can use the trip planner to edit and save your route as a trip.

1. Select **Apps** > **Trip Planner** > **Saved Trips** > **My Active Route**.
2. Edit your route using any of the trip planner features.

   The route recalculates each time you make a change.
3. Select **Save** to save your route as a trip, which you can navigate again later (optional).

photoLive Traffic Cameras

Before you can use this feature, your device must be connected to the Garmin Drive app (*Live Services, Traffic, and Smartphone Features*, page 11).

photoLive traffic cameras provide live images of traffic conditions on major roadways and intersections.

The photoLive service is not available in all areas.

Viewing and Saving photoLive Traffic Cameras

You can view live images from nearby traffic cameras. You can also save traffic cameras for areas you travel frequently.

1. Select **Apps** > **photoLive**.
2. Select **Touch to Add**
3. Select a road.
4. Select a traffic camera location.

   A preview of the live image from the camera appears next to a map of the camera's location. You can select the image preview to view the full-sized image.
5. Select **Save** to save the camera (optional).

   A thumbnail image preview of the camera is added to the main screen of the photoLive app.

Viewing photoLive Traffic Cameras on the Map

The photoLive map tool shows traffic cameras from the road ahead of you.

1. From the map, select ⋮ > **photoLive**.

   The device shows the live image from the nearest traffic camera on the road ahead, along with the distance to the camera. When you pass the camera, the device loads the live image of the next camera on the road.
2. If no cameras are found for the road, select **Find Cameras** to view or save nearby traffic cameras (optional).

Saving a Traffic Camera

1. Select **Apps** > **photoLive**.
2. Select **Touch to Add**.
3. Select a road.
4. Select an intersection.
5. Select **Save**.

Viewing Previous Routes and Destinations

Before you can use this feature, you must enable the travel history feature (*Device and Privacy Settings*, page 19).

You can view your previous routes and places you have stopped on the map.

Select **Apps** > **Trip History**.

Settings

Map and Vehicle Settings

Select **Settings** > **Map & Vehicle**.

Vehicle: Sets the vehicle icon that represents your position on the map.

Driving Map View: Sets the perspective on the map.

Map Detail: Sets the level of detail on the map. More detail may cause the map to draw slower.

Map Theme: Changes the color of the map data.

Map Layers: Sets the data that appears on the map page (*Customizing the Map Layers*, page 11).

Auto Zoom: Automatically selects the zoom level for optimal use of your map. When disabled, you must zoom in or out manually.

myMaps: Sets which installed maps the device uses.

Enabling Maps

You can enable map products installed on your device.

TIP: To purchase additional map products, go to http://buy.garmin.com.

1. Select **Settings** > **Map & Vehicle** > **myMaps**.
2. Select a map.

Navigation Settings

Select **Settings** > **Navigation**.

Calculation Mode: Sets the route calculation method.

Avoidances: Sets road features to avoid on a route.

Custom Avoidances: Allows you to avoid specific roads or areas.

Toll Roads: Sets preferences for avoiding toll roads.

Tolls and Fees: Sets preferences for avoiding toll roads and toll stickers.

NOTE: This feature is not available in all areas.

Environmental Zones: Sets the avoidance preferences for areas with environmental or emissions restrictions that may apply to your vehicle.

Restricted Mode: Disables all functions that require significant operator attention.

GPS Simulator: Stops the device from receiving a GPS signal, and saves battery power.

Calculation Mode Settings

Select **Settings** > **Navigation** > **Calculation Mode**.

The route calculation is based on road speeds and vehicle acceleration data for a given route.

Faster Time: Calculates routes that are faster to drive but can be longer in distance.

Off Road: Calculates a direct line from your location to your destination.

Setting a Simulated Location

If you are indoors or not receiving satellite signals, you can use the GPS simulator to plan routes from a simulated location.

1. Select **Settings** > **Navigation** > **GPS Simulator**.
2. From the main menu, select **View Map**.
3. Tap the map twice to select an area.

   The address of the location appears at the bottom of the screen.
4. Select the location description.
5. Select **Set Location**.

Wireless Network Settings

The wireless network settings allow you to manage Wi-Fi® networks, paired Bluetooth devices, and Bluetooth features.

Select **Settings** > **Wireless Networks**.

Bluetooth: Enables Bluetooth wireless technology.

Paired Device Name: The names of paired Bluetooth devices appear in the menu. You can select a device name to change Bluetooth feature settings for that device.

Search for Devices: Searches for nearby Bluetooth devices.

Friendly Name: Allows you to enter a friendly name that identifies your device on other devices with Bluetooth wireless technology.

Wi-Fi: Enables the Wi-Fi radio.

Saved Networks: Allows you to edit or remove saved networks.

Search for Networks: Searches for nearby Wi-Fi networks (*Connecting to a Wi-Fi Network*, page 20).

Driver Assistance Settings

Select **Settings** > **Driver Assistance**.

Driver Alerts: Allows you to enable or disable alerts for upcoming zones or road conditions (*Driver Awareness Features and Alerts*, page 2).

Speeding Alert: Alerts you when you are exceeding the speed limit.

Route Preview: Shows a preview of the major roads in your route when you start navigation.

Break Planning: Reminds you to take a break and shows upcoming services after you drive for an extended time. You can enable or disable break reminders and upcoming service suggestions.

Proximity Alerts: Alerts you when you approach speed cameras or red light cameras.

Proximity Alerts Settings

NOTE: You must have custom points of interest (POIs) loaded for proximity points alerts to display.

NOTE: This feature is not available in all areas.

Select **Settings** > **Driver Assistance** > **Proximity Alerts**.

Audio: Sets the style of alert that plays when you approach proximity points.

Alerts: Sets the type of proximity points for which alerts are played.

Backup Camera Settings

The backup camera settings allow you to manage paired Garmin backup cameras and camera settings. This menu appears on your navigation device only when the device is connected to a wireless camera receiver cable. See the owner's manual for your backup camera for detailed information about pairing cameras and camera settings. Go to garmin.com/backupcamera to purchase a Garmin backup camera.

Select **Settings** > **Wireless Camera**, and select a paired camera.

Unpair: Removes the paired camera. You must pair the camera again before you can view it using this device and cable.

Rename: Allows you to rename the paired camera.

Guidance Lines: Shows or hides guidance lines and allows you to adjust the position of the guidance lines.

Display Settings

Select **Settings** > **Display**.

Color Mode: Allows you to select day or night color mode. If you select the Auto option, the device automatically switches to day or night colors based on the time of day.

Brightness: Allows you to adjust the display brightness.

Display Timeout: Allows you to set the amount of idle time before your device enters sleep mode while using battery power.

Screenshot: Allows you to take a picture of the device screen. Screenshots are saved in the Screenshot folder of the device storage.

Traffic Settings

From the main menu, select **Settings** > **Traffic**.

Traffic: Enables traffic.

Optimize Route: Enables the device to use optimized alternate routes automatically or upon request (*Avoiding Traffic Delays on Your Route*, page 9).

Traffic Alerts: Sets the traffic delay severity for which the device displays a traffic alert.

Units and Time Settings

To open the Units and Time settings page, from the main menu, select **Settings** > **Units & Time**.

Current Time: Sets the device time.

Time Format: Allows you to select a 12-hour, 24-hour, or UTC display time.

Units: Sets the unit of measure used for distances.

Position Format: Sets the coordinate format and datum used for geographical coordinates.

Setting the Time

1. From the main menu, select the time.
2. Select an option:
   - To set the time automatically using GPS information, select **Automatic**.
   - To set the time manually, drag the numbers up or down.

Language and Keyboard Settings

To open the Language and Keyboard settings, from the main menu, select **Settings** > **Language & Keyboard**.

Voice Language: Sets the language for voice prompts.

Text Language: Sets all on-screen text to the selected language.

NOTE: Changing the text language does not change the language of user-entered data or map data, such as street names.

Keyboard Language: Enables keyboard languages.

Device and Privacy Settings

Select **Settings** > **Device**.

About: Displays the software version number, the unit ID number, and information on several other software features.

Regulatory: Displays regulatory markings and information.

EULAs: Displays the end-user license agreements.

NOTE: You need this information when you update the system software or purchase additional map data.

Software Licenses: Displays software licensing information.

Device Data Reporting: Shares anonymous data to improve the device.

Travel History: Allows the device to store a record of the places you go. This allows you to view the trip log, use the Trip History feature, and use myTrends suggested routes.

Reset: Allows you to clear your travel history, reset settings, or delete all user data.

Resetting Data and Settings

The device offers several options for deleting your user data and resetting all settings to the factory default values.

1. Select **Settings** > **Device** > **Reset**.
2. Select an option:
   - To clear your travel history, select **Clear Travel History**.

     This option deletes all records of the places you have traveled. It does not delete saved locations or installed maps.
   - To reset all settings to the factory default values, select **Reset Default Settings**.

     This option does not delete any user data.
   - To delete all user data and reset all settings to the factory default values, select **Delete Data and Reset Settings**.

     This option deletes all user data, including your saved locations, recently found locations, and travel history. Installed maps are not deleted.

Device Information

Viewing E-label Regulatory and Compliance Information

1. From the settings menu, swipe to the bottom of the menu.
2. Select **Device** > **Regulatory**.

Specifications

Operating temperature range	From -20° to 55°C (from -4° to 131°F)
Charging temperature range	From 0° to 45°C (from 32° to 113°F)
Radio frequency/ protocol	2.4 GHz @ 13 dBm
Power input	Vehicle power using the included vehicle power cable. AC power using an optional accessory (for home and office use only).
Battery type	Rechargeable lithium-ion

Charging the Device

NOTE: This Class III product shall be powered by an LPS power supply.

You can charge the battery in the device using any of these methods.

- Connect the device to vehicle power.
- Connect the device to an optional power adapter accessory, such as a wall power adapter.

  You can purchase an approved Garmin AC-DC adapter suitable for home or office use from a Garmin dealer or www.garmin.com. The device may charge slowly when connected to a third-party adapter.

Device Maintenance

Garmin Support Center

Go to support.garmin.com for help and information, such as product manuals, frequently asked questions, videos, and customer support.

Map and Software Updates

For the best navigation experience, you should keep the maps and software on your device up to date.

Map updates provide the newest available changes to roads and locations in the maps used by your device. Keeping maps up to date helps your device find recently added locations and calculate more accurate routes. Map updates are large and may take several hours to complete.

Software updates provide changes and improvements to the device features and operation. Software updates are small and take a few minutes to complete.

You can update your device using two methods.

- You can connect the device to a Wi-Fi network to update directly on the device (recommended). This option allows you to update your device conveniently without connecting it to a computer.
- You can connect the device to a computer and update it using the Garmin Express application (garmin.com/express).

Connecting to a Wi-Fi Network

The first time you turn on the device, it prompts you to connect to a Wi-Fi network and register your device. You can also connect to a Wi-Fi network using the settings menu.

1. Select **Settings** > **Wireless Networks**.
2. If necessary, select **Wi-Fi** to enable Wi-Fi technology.
3. Select **Search for Networks**.

   The device displays a list of nearby Wi-Fi networks.
4. Select a network.
5. If necessary, enter the password for the network, and select **Done**.

The device connects to the network, and the network is added to the list of saved networks. The device reconnects to this network automatically when it is within range.

Updating Maps and Software Using a Wi-Fi Network

NOTICE

Map and software updates may require the device to download large files. Regular data limits or charges from your Internet service provider apply. Contact your Internet service provider for more information about data limits or charges.

You can update the maps and software by connecting your device to a Wi-Fi network that provides access to the Internet. This allows you to keep your device up to date without connecting it to a computer.

1. Connect the device to a Wi-Fi network (*Connecting to a Wi-Fi Network*, page 20).

   While connected to a Wi-Fi network, the device checks for available updates. When an update is available, appears on the Settings icon in the main menu.
2. Select **Settings** > **Updates**.

   The device checks for available updates. When an update is available, **Update Available** appears below Map or Software.
3. Select an option:
   - To install all available updates, select **Install All**.
   - To install only map updates, select **Map** > **Install All**.
   - To install only software updates, select **Software** > **Install All**.
4. Read the license agreements, and select **Accept All** to accept the agreements.

   NOTE: If you do not agree with the license terms, you can select Reject. This stops the update process. You cannot install updates until you accept the license agreements.
5. Using the included USB cable, connect the device to external power, and select **Continue** (*Charging the Device*, page 20).

   For the best results, a USB wall charger that provides at least 1 A power output is recommended. Many USB power adapters for smartphones, tablets, or portable media devices may be compatible.
6. Keep the device connected to external power and within range of the Wi-Fi network until the update process is complete.

TIP: If a map update is interrupted or canceled before it completes, your device may be missing map data. To repair missing map data, you must update the maps again using either Wi-Fi or Garmin Express.

Updating Maps and Software with Garmin Express

You can use the Garmin Express application to download and install the latest map and software updates for your device.

1. If you do not have the Garmin Express application installed on your computer, go to garmin.com/express and follow the on-screen instructions to install it (*Installing Garmin Express*, page 21).
2. Open the Garmin Express application.
3. Connect your device to your computer using a mini-USB cable.

   The small end of the cable connects to the mini-USB port ① on your dēzl device, and the large end connects to an available USB port on your computer.



4 When your dēzl device prompts you to enter file transfer mode, select **Continue**.

5 In the Garmin Express application, click **Add a Device**.

The Garmin Express application searches for your device and displays the device name and serial number.

6 Click **Add Device**, and follow the on-screen instructions to add your device to the Garmin Express application.

When setup is complete, the Garmin Express application displays the updates available for your device.

7 Select an option:

- To install all available updates, click **Install All**.
- To install a specific update, click **View Details**, and click **Install** next to the update you want.

The Garmin Express application downloads and installs the updates onto your device. Map updates are very large, and this process may take a long time on slower internet connections.

NOTE: If a map update is too large for the internal storage of the device, the software may prompt you to install a microSD® card in your device to add storage space (*Installing a Memory Card for Maps and Data*, page 22).

8 Follow the on-screen instructions during the update process to finish installing updates.

For example, during the update process, the Garmin Express application may instruct you to disconnect and reconnect your device.

Installing Garmin Express

The Garmin Express application is available for Windows® and Mac® computers.

1 On your computer, go to garmin.com/express.

2 Select an option:

- To view the system requirements and verify the Garmin Express application is compatible with your computer, select **System Requirements**.
- To install on a Windows computer, select **Download for Windows**.
- To install on a Mac computer, select **Download for Mac**.

3 Open the downloaded file, and follow the on-screen instructions to complete the installation.

Device Care

NOTICE

Avoid dropping your device.

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Never use a hard or sharp object to operate the touchscreen, or damage may result.

Cleaning the Outer Casing

NOTICE

Avoid chemical cleaners and solvents that can damage plastic components.

1 Clean the outer casing of the device (not the touchscreen) using a cloth dampened with a mild detergent solution.

2 Wipe the device dry.

Cleaning the Touchscreen

1 Use a soft, clean, lint-free cloth.

2 If necessary, lightly dampen the cloth with water.

3 If using a dampened cloth, turn off the device and disconnect the device from power.

4 Gently wipe the screen with the cloth.

Avoiding Theft

- Remove the device and mount from sight when not in use.
- Remove the residue left on the windshield by the suction cup.
- Do not keep your unit in the glove compartment.
- Register your device using the Garmin Express software (garmin.com/express).

Restarting the Device

You can restart your device if it stops functioning.

Hold the power key for 12 seconds.

Removing the Device, Mount, and Suction Cup

Removing the Device from the Mount

1 Press the release tab or button on the mount.

2 Tilt the bottom of the device upward, and lift the device from the mount.

Removing the Mount from the Suction Cup

1 Turn the device mount to the right or left.

2 Apply pressure until the socket on the mount releases the ball on the suction cup.

Removing the Suction Cup from the Windshield

1 Flip the lever on the suction cup toward you.

2 Pull the tab on the suction cup toward you.

Changing the Fuse in the Vehicle Power Cable

NOTICE

When replacing the fuse, do not lose any of the small pieces and make sure they are put back in the proper position. The vehicle power cable does not work unless it is assembled correctly.

If your device does not charge in your vehicle, you may need to replace the fuse located at the tip of the vehicle adapter.

1 Rotate the end piece ① counter clockwise to unlock it.

TIP: You may need to use a coin to remove the end piece.

2 Remove the end piece, the silver tip ②, and the fuse ③.

3 Insert a new fast-blow fuse that has the same current, such as 1 A or 2 A.
4 Place the silver tip in the end piece.
5 Push in the end piece and rotate it clockwise to lock it back into the vehicle power cable ④.

Troubleshooting

The suction cup will not stay on my windshield

1 Clean the suction cup and windshield with rubbing alcohol.
2 Dry with a clean, dry cloth.
3 Mount the suction cup (*Mounting and Powering the dēzl Device in Your Vehicle*, page 1).

My device is not acquiring satellite signals

- Verify the GPS simulator is turned off (*Navigation Settings*, page 18).
- Take your device out of parking garages and away from tall buildings and trees.
- Remain stationary for several minutes.

The device does not charge in my vehicle

- Check the fuse in the vehicle power cable (*Changing the Fuse in the Vehicle Power Cable*, page 21).
- Verify the vehicle is turned on and is supplying power to the power outlet.
- Verify the interior temperature of the vehicle is within the charging temperature range indicated in the specifications.
- In the vehicle fuse box, verify the fuse for the vehicle power outlet is not broken.

My battery does not stay charged for very long

- Decrease the screen brightness (*Display Settings*, page 19).
- Shorten the display timeout (*Display Settings*, page 19).
- Decrease the volume (*Adjusting the Volume*, page 2).
- Turn off the wi-fi radio when it is not in use (*Wireless Network Settings*, page 18).
- Put the device in power saving mode when not in use.
- Keep your device away from extreme temperatures.
- Do not leave your device in direct sunlight.

My device does not connect to my phone

- Select **Settings** > **Wireless Networks**.

  The Bluetooth option must be enabled.
- Enable Bluetooth wireless technology on your phone and bring your phone within 10 m (33 ft.) of the device.
- Verify your phone is compatible.

  Go to www.garmin.com/bluetooth for more information.
- Complete the pairing process again.

  To repeat the pairing process, you must unpair your phone and device (*Deleting a Paired Phone*, page 13), and complete the pairing process (*Live Services, Traffic, and Smartphone Features*, page 11).

Appendix

Installing a Memory Card for Maps and Data

You can install a memory card to increase the storage space for maps and other data on your device. You can purchase memory cards from an electronics supplier, or go to www.garmin.com/maps to purchase a memory card with pre-loaded Garmin mapping software. The device supports microSD memory cards from 4 to 32 GB. Memory cards must use the FAT32 file system format. Memory cards greater than 32 GB must be formatted using the device.

1 Locate the map and data memory card slot on your device (*dēzl OTR700 / LGV700 Device Overview*, page 1).
2 Insert a memory card into the slot.
3 Press it in until it clicks.

Data Management

You can store files on your device. The device has a memory card slot for additional data storage.

NOTE: The device is compatible with Windows 7 and newer, and Mac OS 10.4 and newer.

About Memory Cards

You can purchase memory cards from an electronics supplier, or purchase pre-loaded Garmin mapping software (www.garmin.com). Memory cards can be used to store files such as maps and custom POIs.

Connecting the Device to Your Computer

You can connect the device to your computer using a USB cable.

1 Plug the small end of the USB cable into the port on the device.
2 Plug the larger end of the USB cable into a port on your computer.
3 When your dēzl device prompts you to enter file transfer mode, select **Continue**.

A picture of your device connected to a computer appears on the device screen.

Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.

Transferring Data From Your Computer

1 Connect the device to your computer (*Connecting the Device to Your Computer*, page 22).

  Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.
2 On your computer, open the file browser.
3 Select a file.
4 Select **Edit** > **Copy**.
5 Browse to a folder on the device.

  NOTE: For a removable drive or volume, you should not place files in the Garmin folder.
6 Select **Edit** > **Paste**.

Disconnecting the USB Cable

If your device is connected to your computer as a removable drive or volume, you must safely disconnect your device from your computer to avoid data loss. If your device is connected to your Windows computer as a portable device, it is not necessary to safely disconnect the device.

1 Complete an action:
  - For Windows computers, select the **Safely Remove Hardware** icon in the system tray, and select your device.

- For Apple® computers, select the device, and select **File** > **Eject**.

2. Disconnect the cable from your computer.

Viewing GPS Signal Status

Hold for three seconds.

Purchasing Additional Maps

1. Go to your device product page at garmin.com.
2. Click the **Maps** tab.
3. Follow the on-screen instructions.

Purchasing Accessories

Go to garmin.com/accessories.

Index

Symbols
2-D map view **11**
3-D map view **11**

A
accessories **23**
active lane guidance **7**
addresses, finding **3, 12**
alerts **2**
  audio **19**
  proximity points **19**
answering calls **13**
audio, proximity points **19**
avoidances **9**
  area **9**
  deleting **9**
  disabling **9**
  road **9**
  road features **9**
  tolls **9**

B
backup camera **19**
battery
  charging **1, 20, 22**
  maximizing **22**
  problems **22**
Bluetooth technology **11–13, 15, 22**
  pairing a phone **11**
  settings **18**
Bluetooth Technology, disabling calls **11, 12**
break planning **14**
breakdown directory **4**
brightness **2, 16**

C
calls **13**
  answering **13**
  contacts **13**
  dialing **13**
  history **13**
  home **13**
  placing **13, 16**
cameras
  backup **19**
  red light **3**
  speed **3**
changing the search area **4**
charging the device **1, 20, 22**
cleaning the device **21**
cleaning the touchscreen **21**
computer, connecting **22**
connecting **20**
coordinates **5**
current location **6**

D
deleting
  all user data **19**
  paired Bluetooth device **13**
  service categories **16**
  service records **16**
  trips **17**
destinations **18**. *See* locations
  arriving **8**
detours **8**
device care **21**
diagnostics **15**
dialing **13**
directions **7**
display settings **19**
driver alerts **2, 3**
driving directions **7**

E
editing, saved trips **17**
emergency services **6**
EULAs **19**
exit services **10**
exporting
  jurisdiction summaries **15**
  trip reports **15**

F
files, transferring **22**
finding locations. **3–5** *See also* locations
  addresses **3**
  categories **4**
  cities **10**
  coordinates **5**
  intersections **5**
Foursquare **5**
fuel, stations **6**
fuel data **15**
fuse, changing **21**

G
Garmin Connect **11**
Garmin Express **21**
  updating software **20**
geocaching **5**
going home **7**
GPS **1, 23**

H
hands-free phone calls **11, 12**
home
  calling **13**
  editing location **7**
  going **7**
  phone number **13**
hours of service **14, 15**

I
icons, status bar **1**
ID number **19**
initial setup **15**
International Fuel Tax Agreement (IFTA) **15**
  exported summaries and reports **15**
  fuel data **15**
  jurisdiction summary **15**
  trip reports **15**
intersections, finding **5**

J
jurisdiction summary **15**

K
keyboard
  language **19**
  layout **19**

L
language
  keyboard **19**
  voice **19**
latitude and longitude **5**
location **5**
locations **3, 18**
  calling **13**
  current **6**
  recently found **6**
  saving **6**
  searching for **3, 5**
  simulated **18**

M
malfunctions **15**
map layers, customizing **11**
map view
  2-D **11**
  3-D **11**
maps **7, 9, 10, 18**
  data field **7, 10, 11**
  detail level **18**
  layers **11**
  purchasing **23**
  symbols **7**
  theme **18**
  tools **10**
  updating **20**
  viewing routes **7**
memory card **1, 22**
  installing **22**
microSD card **1, 22**
mount, removing **21**
mounting the device
  automobile **1**
  removing from mount **21**
  suction cup **1, 21**
myTrends, routes **9**

N
navigation **5, 7, 8, 16**
  settings **18**
next turn **7**
notifications **11, 12, 15**

O
on-screen buttons **2**
owner's manual **16**

P
pairing **15**
  phone **11, 22**
parking **4–6, 8**
phone
  disconnecting **13**
  pairing **11, 22**
phone book **13**
phone calls **13**
  answering **13**
  dialing **13**
  muting **13**
  voice dial **13**
photoLive **18**
points of interest (POI) **4, 5**
  trucking **4**
power cables **20**
  changing the fuse **21**
  vehicle **1**
power key **1**
product support **16**
profiles
  activating **2**
  truck **2**
proximity points alerts, settings **19**

Q
Quick Search **4**

R
recently found locations **6**
red light cameras **3**
removing mount **21**
reports, trip **15**
resetting
  device **21**
  trip data **11**
resetting the device **19**
restrictions, vehicle **2**
road conditions, weather **17**
routes **6**
  adding a point **8, 17**
  calculating **8**
  calculation mode **17, 18**
  myTrends **9**
  shaping **8**
  starting **4, 7**
  stopping **9**
  suggested **9**
  viewing on the map **7**

S
satellite signals
  acquiring **1**
  viewing **23**
saved locations **17**
  categories **6**
  deleting **6**
  editing **6**

saving, current location **6**
screen, brightness **2**
screenshots **19**
search bar **3**
service history
  categories **16**
  deleting **16**
  editing **16**
  records **16**
settings **18, 19**
shaping a route **8**
simulated locations **18**
sleep mode **1**
smartphone features **11, 12**
  connecting **11**
  disabling calls **11, 12**
software
  updating **20**
  version **19, 21**
speaking commands **16**
specifications **20**
speech recognition **16**
speed cameras **3**
suction cup **21**

T
theft, avoiding **21**
time settings **19**
timer **14**
tolls, avoiding **9**
tools, maps **10**
traffic **11, 13, 14, 19**
  adding subscriptions **14**
  alternate route **9**
  cameras **18**
  incidents **11, 14**
  map **11, 14**
  receiver **14**
  searching for delays **11, 14**
traffic cameras, viewing **18**
travel history **19**
trip information **10**
  resetting **11**
  viewing **11**
trip planner **17**
  editing a trip **17**
  shaping points **17**
TripAdvisor **5**
troubleshooting **22**
truck
  points of interest **4**
  profiles **2**
  trailer **2**
turn list **7**

U
unit ID **19**
up ahead **10**
  customizing **10**
updating
  maps **20**
  software **20**
USB, disconnecting **22**

V
vehicle power cable **1**
vehicle profile, truck **2**
voice command **16**
  activating **16**
  tips **16**
voice dial **13**
volume, adjusting **2, 16**

W
weather **16**
  radar **17**
  road conditions **17**
Where Am I? **6**
Wi-Fi **18, 20**
wireless camera **19**

CE

May 2020

GUID-4305I9C4-E07D-4IFA-A2ID-EIF2E797924E v1